

2019+ intake shield installation instructions

Note* Recommended to use blue loctite or equivalent on all hardware

Install DLP intake system per the intake installation instructions

Upper shield installation

1. Set the lower half of the upper shield on top of the engine
2. Install the front mounting tab to the factory airbox mounting location
3. Install the lower mount with the airbox mounting brackets utilizing the same bolt and lock nut
4. Slide the upper half of the upper shield into the front slots in the lower half (the air/oil separator may need to be twisted slightly for proper fit)
5. Pivot the back half down until the bolt holes align and install the two bolts
6. Using cable ties, secure the passenger side of the shield to the frame

Lower shield installation

1. Install rubber grommets into the large holes on the bottom of the shield
2. Set shield in place and hand tighten the upper bolt
3. Center the bottom of the shield against the motor mount
4. Mark the center of the holes
5. Remove the shield
6. Drill the two holes with a 9/32" drill bit
7. Insert the two clips over the drilled holes
8. Reinstall the shield
9. Finger tighten the upper bolt once more
10. Thread the two step bolts and washers through the rubber grommets and into the clips installed on the motor mount
11. Tighten all hardware