



High/Low boost switch harness installation notes

- Unplug the electronic boost controller from the OEM harness.
- Plug in the new harness in between both of those connectors.
- Run the harness along the inside of the center console towards the front of the car.
- Drill a 13/16" hole and mount the button in your desired area. (where the harness will reach)
- Connect the wiring harness to the button. (polarity is not important)
- Make sure to secure the wiring out of the way of all moving parts and sharp objects.

Thank you for your purchase, please contact us directly with any questions.

Beyond Redline Performance
1215 N Buchanan St
Green Bay WI 54303
920-498-1223