

Dirt Launch Powersports Yamaha YXZ1000R Shock Tower Brace Installation Instructions

1. Trim the plastic directly above the shock tower to make room for the brace.
2. Safely lift the front of the vehicle and place it on jack stands.
3. ***IMPORTANT* VERIFY FRONT SUSPENSION IS UNCOMPRESSED.**
4. Remove the top mounting bolts from the front shocks.
5. Mount the shock brace to the chassis with the two bolts removed in step 5 unless using the optional upgraded bolts to replace the factory 2 mounting bolts.
6. Install the small bolt supplied in the kit from the bottom side of the shock mount into the center of the shock brace with loctite as pictured below.



7. Once those are all tight, attach the top of the shocks to the brace using the long bolts, washers, and lock nuts supplied in the kit.
8. Verify all bolts are tight, lower vehicle, and enjoy!